The thickness of the wood can be what you want. I used  $\frac{3}{4}$ " thick walnut. The length of the middle stretchers is contingent on the size of your pot. Measure your pots radius and add one half inch. Add half lap joint to center.

